H BROCO

CD ACCESSORIES

| | ТҮРЕ | OAL | STANDARD | METRIC | |
|---|------------------------|--------|--|----------|--|
| | "B" Style | 1-3/8″ | 14ga-1/2" | 3mm-10mm | |
| 1 | IWT-Soyer Style | 1-5/8″ | 14ga-1/2" | 3mm-10mm | |
| | Nelson Style | 2-3/8″ | 14ga-1/2" | 3mm-10mm | |
| | "N" Taper Chuck | 2-1/2" | 12ga-1/2" | 3mm-10mm | |
| | Magnetic Cuphead Chuck | 1-7/8" | Available in one piece, assembly or non-magnetic | | |

Collets are designed to hold the stud tightly. If a collet is worn, arced or bent it should be replaced. Other sizes and makes are available for most stud welding equipment on the market today.

STOPS



| ТҮРЕ | SIZES |
|----------------------|---|
| "B" Stop | Universal, button and custom length |
| IWT-Soyer Style Stop | Included with collet (threaded piece & nut) |
| Nelson Style Stop | Dependent on stud length range |
| "A" Stop | Universal, button and custom length |

Stops are designed to stop the stud from bottoming out against the collet and causing premature failure of the collet. Other sizes and makes are available for most stud welding equipment on the market today.

ADAPTORS



| DESCRIPTION | FUNCTION | OPTIONS |
|------------------------------------|---|--------------------------|
| Collet Protector/ Collet Insert | Used when welding long pins. With stop removed, pin is allowed to feed through gun shaft. Collet protector and insert isolate the pin from the collet | 10, 12 and 14 gauge |
| Collet | Used for acceptance of different style collets and chucks | B-N, B-CL, N-B |
| Adaptor | Used for acceptance of different style conets and chucks | |
| Template | Replaces gun faceplate and used as a template locator | 7/8", 1", 1-1/4" |
| Adaptor | replaces gui l'aceptate and used as a template locator | |
| Shaft | Used for accessing deep weld locations | 2"-10" |
| Extension | Used for accessing deep werd locations | 2 -10 |
| Remote Flexible | Used for accessing hard to reach weld locations | 3" Standard |
| Collet Extender | | (Custom sizes available) |

There are numerous adaptors available. The most common ones have been listed. If you have a tough application we are happy to recommend the proper adaptor.

LEGS AND FEET



| Description | Details |
|---------------|---|
| CD Legs | 5/16"diameter x 7" through 14" |
| CD Foot Piece | Closed or Split |
| Leg Screw | 10-32 |
| Leg Washer | #10 |
| Spark Shield | Used to contain spark during weld cycle. Can also be used as a template adaptor. Vent- ed, Non-Vented, large(#8-3/8") and small (14 ga-#6) |

Legs are required for proper gun set up. Other styles and makes are available. Please call with requirements.

800-458-9353 www.hybrocosales.com

<u>COLLETS</u>